
Removing the engine



Order	Job/Parts to remove	Q'ty	Remarks
1	Engine mounting bolt (right front upper side)/ Engine mounting bolt (left front upper side)	1/1	
2	Engine bracket bolt (right)/Engine bracket bolt (left)	2/2	
3	Engine bracket (right)	1	
4	Engine bracket (left)	1	
5	Engine mounting bolt (right front lower side)	1	
6	Collar	1	
7	Collar	1	
8	Engine mounting bolt (left front lower side)	1	
9	Engine mounting nut (lower)	1	
10	Muffler bracket bolt	1	
11	Muffler bracket	1	
12	Sidestand switch coupler	1	Disconnect.
13	Muffler bracket bolt	1	
14	Muffler bracket	1	
15	Pivot shaft nut	1	Loosen.